



# Product Data Sheet

**Q7621 Air Assist CARB Compliant Contact Adhesive**  
Fast Tack, Water-Resistant, CARB Compliant

Q7621 Air Assist CARB Compliant Contact Adhesive

## Features

- High Strength, High Shear
- Quick Tack Formula
- No Ozone Depleting Substances
- Water-Resistant Bond
- Great for Multiple Substrates

## Description

Quality Aerosols Q7621 Air Assist CARB Compliant Contact Adhesive is a high strength, high shear, fast tack adhesive developed exclusively to work like a pressure pot system. It can be used on wood, particle board, plastic, fiberglass insulation and many other substrates. It has a quick tack with high solids and a water resistant bond.

## Applications

Q7621 is used for the permanent bonding of wood, particle board, plywood, FRP board, plastics, fiberglass insulation and many other substrates.

## Product Usage

Q7621 Adhesive is designed as a two surface bonding application. Both surfaces need to be dry and clean of oil and debris. Spray an even coat of adhesive to cover 80%-100% of the surfaces. Allow solvents to dry 3-5 minutes until the adhesive becomes tacky. For porous surfaces it is recommended to apply a second coat after the first coat has become tacky. Put the coated surfaces together and apply uniform pressure. Full adhesive strength will be reached in 24 hours.

## Storage

Store in a cool, dry, and well ventilated area. Do not handle or store near open flame or other heat sources. We recommend storing at or above 65°F. Bulk and canister products should be kept off the floor.

For More Innovative Products from Quality Aerosols  
Visit us at [www.qualityaerosols.com](http://www.qualityaerosols.com)

## Product Specifications

<b>Color</b>	Clear to Yellow or Red
<b>Solids</b>	32.1% +/- 2%
<b>VOC g/L</b>	24.5% / 201 g/L
<b>VOC Compliant CARB/OTC</b>	Yes (Does not meet SCAQMD rule 1168)
<b>Bonding Range</b>	3-60 hours
<b>Dry/Tack Time</b>	3-5 minutes
<b>Spray Pattern</b>	Determined by used
<b>Sizes Offered</b>	9#, 30#, 145#, 270#
<b>Warranty Period</b>	1 year from manufacture date
<b>Square Feet Coverage</b>	9# - approx 418 ft <sup>2</sup> @ 2g 30# - approx 1392 ft <sup>2</sup> @ 2g 145# - approx 6264 ft <sup>2</sup> @ 2g 270# - approx 12,528 ft <sup>2</sup> @ 2g

Note: all results are based on 2g dried glue/ft<sup>2</sup>

